

Anchorage for anti-rolling continuous concrete joists placed on a prefabricated concrete structural element. Assembled with C10-60 threaded coupler, VR10 threaded bar, M10 washer, M10 Glower washer and M10 nut.





Anchor BIG-80




www.noxifer.com




Material: DX51D+Z
Surface treatment: Sendzimir Galvanized
Service load: 190 kg per support point
Concrete: \geq HA-35

	Anchorage for joist	BIG-80
	Threaded bar length 200 mm Threaded bar length 220 mm	VR10-200 VR10-220
	Threaded coupler M10	C10-60
	Nut M10	M10

1

- 1.1.- Place threaded coupler into precast concrete element (precast factory).
- 1.2.- Screw threaded bar length 200/220 into coupler.
- 1.3.- Fixing of BIG-80 item through nut. Glower washer must be completely flat.

2

2.1.- Final checking of process. Nut strongly tightened.

In order to continue the assembly sequence all the steps above described must be successfully overcome